

Voice alerts




Panel mount HMI speaker

Voice alerts are given so that an operator away from the system can notice the alerts. Voice volume and language can be selected according to the operating environment.

For details, refer to page 82. >

No need for periodic screw retightening



Spring clamp junction terminal block, which does not require screws, eliminates risk of screw-loosening due to vibration. Therefore, screw tightening during maintenance is not required, reducing work load of workers.

For details, refer to page 86. >

Preventive maintenance by managing the number of uses



RFID interface module

Managing the number of uses of the life-expired parts by RFID and replacing the parts before the production line stops can reduce the risk of production line downtime.

For details, refer to page 64. >

Visualization of production sites using camera monitoring



Network camera interface module

Using this product with an HMI (GOT) enables checking images recorded by cameras, controlling camera shooting directions, or recording images when a downtime occurs.

For details, refer to page 56. >

